

# INSTRUCTIONS

## WEATHERPROOF ADAPTER KIT FOR AIR EJECT MODEL # 091-28AK

1. Mount Air Eject to Mounting Plate using (3) #8-32 x 1/2" Screws and lock washer.
2. Mount Air Eject and Mounting Plate, Gasket and Weatherproof Cover to Truck Wall using (4) #8-32 x 1-1/4" Screws, Lock Washer and Hex Nut.
3. Install Coupler Adapter to your Air Line and Female Coupler. This is a tight fit and some force may be required. Be certain that coupler is fully seated in protector.
4. Slide the plastic Protector/Handle over the Air Eject Female Coupler.
5. See your Air Eject Instructions for details on your Air Eject installation.

