


INSTALLATION INSTRUCTIONS

Please read the entire manufactures (InPOWER LLC) owner's manual. This diagram is the recommended wiring for automatic operation on emergency vehicles.

RECOMMENDED WIRING FOR AUTOMATIC OPERATION



For Technical Support or Warranty issues please Contact InPOWER at: 740-548-0965 or 866-548-0965