

MAINTENANCE & INSTALLATION INSTRUCTIONS

AUTO CLEAN 2



Model 091-9G-2

The Auto Clean 2 compressed air filter is the ideal filtering device to provide clean air from an air source to the vehicle air brake system. Uses an ordinary roll of toilet paper as the filter element.

REPLACING THE FILTER ELEMENT

1. Unscrew the "T" handle and remove the housing section.
2. Grasp the contaminated element by inserting the first two fingers of one hand into the core of the element. Place thumb on outer surface of element and rock it sideways vigorously until it is loose. Left element from housing section.
3. Remove large seal and wipe clean, Wipe out seal groove. Replace seal securely and evenly in the groove. Wipe mating surface on the top section.
4. Insert a new filter element* in lower housing section, Place thumbs on inner core of element and push element firmly into place.
5. Replace housing, engage threads, and draw housing sections together by TIGHTENING "T" HANDLE FIRMLY BY HAND.

***REPLACEMENT FILTER ELEMENT** - Use any grade toilet paper roll.

Note: to insure ease of element compression, periodically lubricate the thrust washer area and threads on stud with petroleum jelly or equivalent.

Warning: If a saturated filter element is left in the housing for an extended period of time, a failure of the protective coating on the inside of the housing could occur. Do not exceed the maximum working pressure of 125 PSI.



SINCE 1967, DESIGNERS OF INNOVATIVE PRODUCTS

KUSSMAUL ELECTRONICS COMPANY, INC.

170 CHERRY AVENUE, WEST SAYVILLE, NEW YORK, 11796-1221 USA

TEL. In NY: 631 567-0314

TOLL FREE: 800 346-0857

FAX: 631 567-5826